## INSTALLATION INSTRUCTIONS

6515安裝說明

## 1. Select proper position for installation, paste this **Template** on wall, make sure the drilling holes on the same level, and then drill 10mm holes for Bracket to 70mm depth. 請先選取預定安裝的位置,於牆壁貼上鑽孔定位紙,並確認鑽孔位置是在同水平線上後, 支撐架使用10mm鑽頭鑽孔。

2. Remove Template, and fix Gasket and Bracket with the Anchor Bolts (Bracket). Insert Anchor Bolts (Bracket) with hammer to the hole end and tighten Anchor Bolts (Bracket) with Adjustable Wrench.

將鑽孔定位紙取下,並安裝支撐架至牆面上,膨脹螺絲(支撐架用)穿過支撐架及墊片並 敲至洞孔底,再使用活動或開口扳手鎖緊螺絲,固定住支撐架。

3. Place the **basin** on the **Bracket**, mark the drilling positions, remove the **basin**, and then drill 12.7mm( $\frac{1}{2}$ ") holes for **basin** to 70mm depth. Insert the **Anchor Bolt (Basin)** with hammer to the hole end, remove Nut, Rubber Gasket and one Washer from bolts. Fix the Basin with Rubber Gasket, Washer, and Nut in sequence, and then tighten Nut with Adjustable Wrench to complete the installation.

將臉盆放置在支撐架上,然後劃記安裝記號後,移開臉盆,使用12.7mm(沙")鑽頭鑽孔。 將膨脹螺絲(臉盆用)敲至洞孔底,只取出螺帽、橡皮墊圈和一片華司。再將臉盆裝上, 依序套入橡皮墊圈、華司和螺帽,再使用活動或開口扳手鎖緊螺帽,固定住臉盆。







6515-F3(附墊片)





JUSTIME | 巧時代 | ST SHENG TAI BRASSWARE CO., LTD.