INSTALLATION INSTRUCTIONS

6810安裝說明

- 1. Use **Bracket** as template to locate appropriate drilling centers with pencil 使用固定鐵片和鉛筆在預定鑽孔的位置,畫上記號.
- Use 6mm drilling bit to drill holes in your marked locations, when mounting on drywall, insert **Plastic Anchors**. 當安裝在水泥牆,使用1/4英时鑽頭,鑽孔深度4公分,崁入塑膠塞並使之齊平 於牆面.
- 3. Attach **Bracket** to wall with **Wall Screws**. 將固定鐵片以螺絲鎖在牆面上.
- 4. Locate the **Main Part** on the **Bracket** and secure with **Set Screw**. 在固定鐵片上面掛住產品本體,並以螺絲起子由下方鎖緊埋頭螺絲,完成安裝程序.



JUSTILLE | 巧時代 | ST SHENG TAI BRASSWARE CO., LTD.



www.justime.com

PU68-10-ST00 MADE IN TAIWAN

INSTALLATION INSTRUCTIONS

6810安裝說明

- 1. Use **Bracket** as template to locate appropriate drilling centers with pencil 使用固定鐵片和鉛筆在預定鑽孔的位置,畫上記號.
- Use 6mm drilling bit to drill holes in your marked locations, when mounting on drywall, insert **Plastic Anchors**. 當安裝在水泥牆,使用1/4英时鑽頭,鑽孔深度4公分,崁入塑膠塞並使之齊平 於牆面.
- 3. Attach **Bracket** to wall with **Wall Screws**. 將固定鐵片以螺絲鎖在牆面上.
- 4. Locate the **Main Part** on the **Bracket** and secure with **Set Screw**. 在固定鐵片上面掛住產品本體,並以螺絲起子由下方鎖緊埋頭螺絲,完成安裝程序.



