

INSTALLATION INSTRUCTIONS

6910扶手架 安裝說明

1. Loosen the **Set Screw** and disassemble the **Cover** for installation, install the **Basket** (option) as fig# 1 shown.

請先選取預定安裝的位置,並在牆壁上畫上預定鑽孔記號,如果要安裝雙背板基座的產品,請先確認鑽孔的位置是在同一水平線上,並以產品比對確認鑽孔的距離。

2. Located the **Grab Bar** on proper position, use **Bracket** as template to locate appropriate drilling centers with pencil as fig# 2 shown.

當安裝在水泥牆,使用6mm鑽頭,鑽孔深度4公分,嵌入塑膠塞並使之齊平於牆面,將固定基座以螺絲鎖緊在牆上。

3. Use 6mm drilling bit to drill holes in your marked locations, when mounting on drywall, insert **Plastic Anchors**, attach **Bracket** to wall with **Wall Screws**. Locate the **Cover** onto the **Bracket** and secure with **Set Screw** as fig# 3 shown.

用隨附六角扳手先鬆開本體下方的埋頭螺絲,使本體能順利套進固定基座後,再鎖緊下方的埋頭螺絲,完成安裝程序。

4. The **Basket** can be installed on either left or right side as fig# 4 shown .

籃子可供選擇安裝於左方或右方,如圖示 4 .

