

Water Drinking Faucet 7780-G4-85S1

NO	Part NO.	Part Name	QTY
1	0710-FB-5400	Washer	1
2	0710-FD-68RB	Hex nut	1
3	0780-GQ-5400	Thread Pipe	1
4	C141-00-5101	ORING	1
5	D032-03-5100	Washer	1
6	0700-2N-5400	Fixing Pin	1
7	0780-GM-5400	Pin	1
8	0780-HB-15S1	Main Body	1
9	0780-HD-54SJ	Protection Bow	1
10	0299-B3-5101	O-Ring	1
11	A022-05-62CP	Nozzle	1
12	E046-00-5400	Filter Net	2
13	0752-9N-5101	Rubber Sealing	1
14	0780-GA-15S1	Push Button Cap	1
15	0780-GC-54S1	Push Button Body	1
16	0780-GD-5400	Spindle	1
17	0780-GF-5400	Spindle Head	1
18	0780-GH-5400	Gasket	1
19	0780-GJ-7500	Gasket	1
20	0780-GK-7500	Gasket	1
21	0796-C3-5101	Oring	1
22	0874-BJ-5101	Washer	1
23	C011-50-5101	O-Ring	1
24	C121-00-5101	Oring	1
25	C140-00-5101	Oring	1
26	D032-01-5100	Gasket	1
27	M012-00-5400	Spring	1
28	PJ77-80-STG5	Gasket	1
29	C042-00-5100	Gasket	1
30	E044-00-5400	Filter Net	1

